

## XDJ-RX2 for rekordbox VIDEO



NOTE: Please use with XDJ-RX2 firmware Ver.1.10 or higher and rekordbox dj Ver.5.0 or higher.

Group	No.	Name	Action	Function
<b>BROWSE</b>				
	1	MENU	Press	Open/close rekordbox VIDEO CONTROL window when selecting MEDIA SELECT MIDI.
	2	BACK	Press	Close rekordbox VIDEO CONTROL window.
	3	TEXT PREVIEW ON	Touch	Display text in VIDEO display area. Display text in VIDEO master out window.
	4	IMAGE PREVIEW ON	Touch	Display image in VIDEO display area. Display image in VIDEO master out window.
	5	CAMERA PREVIEW ON	Touch	Display live feed from CAMERA in VIDEO display area. Display live feed from CAMERA in VIDEO master out window.
	6	SLIDESHOW PLAY/PAUSE STOP	Touch	Display and start SLIDE SHOW in VIDEO display area. Pause SLIDE SHOW.
	7	AV SYNC	Touch	Sync the video cross fader and the audio cross fader or cancel it.
	8	TRANSITION FX	Touch	Go to TRANSITION FX selection window.
	9	TRANSITION FX CALL	Touch	Call TRANSITION FX (order as listed)
	10	TRANSITION FX RANDOM	Touch	Call TRANSITION FX (RANDOM)
	11	TRANSITION FX FAVORITE(1~5)	Touch	Call TRANSITION FX set as FAVORITE



Group	No.	Name	Action	Function
<b>1.BROWSE</b>				
	1	Rotary Selector	Turn	Move to next/previous page.
	2	BACK	Press	Back to rekordbox CONTROL window.
	3	BACK	Touch	Back to rekordbox VIDEO CONTROL window.
	4	TRANSITION FX select	Touch	Select TRANSITION FX.